



2011-2014 Ford Mustang GT Installation instructions

Do not attempt this installation if proper safety equipment isn't available to you. Seek the assistance of a professional installer. Read and understand all directions before starting any of the instruction process.

Rear chassis support cross bar may interfere with muffler removal. Loosen and pull down and out of the way. Do not remove pan hard bar.

Loosen muffler clamp bolts, and the sleeve clamps on cat back.
Prying the clamp alignment tab outward allows the clamps to slide rearward.
The rear pipes can be removed.
The Factory sleeve clamp is reused.

Mufflers may now be removed and replaced with Kooks axle back mufflers.
Skip this step if only replacing rear pipes.

Factory pipes may now be reinstalled or replaced with Kooks 3" rear pipes
Loosely tighten all clamps before exhaust alignment.
Align tips and connection pipes making all necessary adjustments.

Tighten 2 bolt sleeve clamps first, recheck tip alignment and tighten ball clamp on muffler.
Replace rear chassis support cross bar bolts and tighten all hardware.

Thank you your purchase, we appreciate your business for.

Kooks Custom Headers – 141 Advantage Place. Statesville, NC 28677
www.kookscustomheaders.com