

2009-2015 Cadillac CTS-V Axle Back Installation Instructions



Do not attempt this installation if proper safety equipment isn't available to you. Seek the assistance of a professional installer.

Requires cutting of the factory exhaust system.

Read and understand all instructions before beginning.

To install this system the following tools are suggested:


-Vehicle Lift or Jack and 4 Jack Stands	-Standard Screwdriver Set
-Ratchet Set (¹ / ₄ " & ³ / ₈ " Drive)	-Safety Glasses
-Metric Socket Set (1/4" & 3/8" Drive)	-Paint Pen or Marker
-Extensions $(1/4" \& 3/8"$ Drive)	-Vehicle Service Manual
- Pry Bar Set	-Thread Locker
$-\frac{7}{8}$ " O ² Socket ($\frac{7}{8}$ " Wrench)	-WD-40 (Penetrating Oil)
-Gasket Scraper	-Anti-seize
-Metric Wrench Set	-Zip Ties

Kooks Custom Headers – 141 Advantage Place Statesville, NC 28677 www.KooksHeaders.com



STOCK AXLE BACK REMOVAL PROCESS

Use the below picture as a reference when cutting the factory system



STEP 1. Factory Axle Back

- Measure 2 ¹/₄" forward from the center line of the differential mount and make a mark horizontal across the pipe.
- Cut factory pipe on that line.
- Carefully Remove the factory axle back



KOOKS AXLE BACK INSTALLATION PROCESS

Clamps should be torqued to 40-45 ft. lbs.

STEP 1. Kooks Axle Back

- Slip front pipes and clamps over factory exhaust (do not tighten clamps yet)
- Attach and hang the remainder of the axle back.

STEP 2. Exhaust Alignment

- Align the exhaust clear of all obstructions
- Tighten all clamps to specified torque

STEP 3. Inspection

- Start Engine and check for any Exhaust Leaks.
- Allow Vehicle to complete one heat cycle (Heat to temp and allow for cooling).
- Re-torque Header Bolts and Header Hardware.

Thank you for your purchase, we appreciate your business. If additional assistance is needed, please contact Kooks Custom Headers Toll free at 1-866-586-KOOK or contact your local dealer.